



Software changes 20240618

- With this improvement some smaller bugfixes were done in the background
- Cooling tank can now works stand alone (no control of what happens after the cooling tank)
- You will see the primary flow temp (EZ360) is you are not working with an indoor sensor

New: Added new option have only cooling tank without heating or cooling system connected to it

- This is a new choice in the menu... Menu "only tank". This system is only cooling a tank, control of fan coils etc is **not done by CTC** but with external controller
- CTC controls the tank temperature not the temperature after the tank, towards the system.
- Define/cooling/cooling tank (Yes/No, new option, **ONLY TANK**)



Bug fix: showed room setpoint for cooling even when room sensor wasn't used

- If no room sensor is used, you will see the primary flow temperature.
- This is for the heating/cooling temperature

