


Software changes 20240820 - 20240822

- Some small software changes has been done in improve our control units
- In the next 2 slides you will find information about the one you may run in to

New function: Shape of heating curve stays when changing the offset

- If you change the offset it will move the curve (shape will be kept)
- With inclination you will change the curve



New function: Room sensor can now be set to “show” in passive cooling

- Before it was not possible to set it, now you can choose between **No** or **Show**
- With ‘**Show**’, the value is not used but the value is only showed
- With ‘**No**’ the value is no used and not showed at all

